

SAC & COOLSAC

HOW TO STORE YOUR MOTORCYCLE USING

THE BIKESAC™

Your BIKESAC™ is designed for long term indoor storage of your motorcycle.

1. Wash your motorcycle completely and dry thoroughly.
2. Let your motorcycle sit for several hours to ensure complete drying.
3. When your motorcycle is in the proper condition for storage, you are ready to SAC™ it up.
4. Lay the bottom (flat section) of the BIKESAC on a clean floor.
5. Pull your motorcycle onto the bottom of the BIKESAC so that the handlebars are positioned at the widest part of the BIKESAC bottom.
6. Place the kickstand pad under the kickstand where it rests on the BIKESAC.
7. Zip up the BIKESAC making sure your motorcycle is aligned and the BIKESAC is adjusted properly.
8. You may want to drape a dry terry cloth towel over the tank and fenders of your motorcycle. This is added protection from falling objects or inadvertent bumps during storage.
9. If you suspect your motorcycle will leak any fluids, place a pan under your motorcycle to catch any leaking fluid.
10. Open the desiccant package and place all the packets under you motorcycle and immediately zip up the BIKESAC.
11. It is recommended that you do not open the BIKESAC until you are ready to take your motorcycle out of storage. The desiccant will work best in a closed environment. You may inspect your motorcycle through the clear BIKESAC.
12. If you do open the BIKESAC, you may purchase new desiccant at you dealer, or you may call 1-800-445-8946 for immediate delivery.
13. **WARNING!** Gas fumes may accumulate inside the BIKESAC during storage. **DO NOT** open the zipper in the presence of a cigarette, spark or open flame.