

SAC & COOLSAC

www.coolsac.com

Cool Down the Road...

INSTALLATION INSTRUCTIONS **FOR KICKSTANDS DYNA FRAME**

1. Have someone hold bike upright. Release spring from post on frame from the right side of motorcycle.
2. Set bike down on kickstand. Remove cotter pin and washer that holds kickstand assembly into frame.
3. Hold bike upright, remove pin that cotter pin holds in place. Fold kickstand halfway up and remove assembly from frame.
4. Remove bolt, lock, and pivot block from stock kickstand and put onto new kickstand using bolt and washers supplied. Lubricate your post with grease and anti-seize.
5. Install kickstand and pivot block back into frame and insert pin through frame.
6. Set bike onto kickstand and install washer and cotter pin. Bend cotter pin tabs to 90 degrees.
7. To re-install spring hold bike upright and stretch spring from left side of bike. This will require vise-grip pliers.
8. Adjust bumper so that kickstand comes as close to frame and primary case without contact.
9. Practice using new kickstand, it should work just like the stock one.

It is a good idea to wax your kickstand with wax or protect-all regularly (we suggest one waxing every two or three months.)

If you have any questions, comments or concerns, please do not hesitate to call us.

Elwood Specialty Products Inc.
2180 Elmwood Ave.
Buffalo NY 14216
Telephone(800)445-8946
Fax(716)874-2110