

# **SAC & COOLSAC**

[www.coolsac.com](http://www.coolsac.com)

**Cool Down the Road...**

## ***INSTALLATION INSTRUCTIONS*** **FOR KICKSTANDS SOFTAIL/FL FRAME**

1. Support motorcycle securely on a motorcycle lift. Bike should be stable before removing the stock side stand.
2. Remove bolt, washer and lock washer.
3. Remove leg stop, noting which side up.
4. Rotate stock stand toward the front of the motorcycle until spring tension is at the minimum level. Remove spring.
5. Drop side stand through bracket sleeve, remove side stand.
6. Remove spring replace with supplied spring.
7. Lubricate the shaft of new kickstand with grease and lift into bracket sleeve.
8. Rotate stand toward the front of the motorcycle until the spring will enter the spring tab on the stand.
9. Rotate stand back to resting position.
10. Replace leg stop, making sure that the correct side up.
11. Replace bolt, washer and lock washer. Replace nut if FL frame. Blue loctite#242 will prevent play in threading,
12. Rotate stand across the full range of motion to ensure smooth operation.
13. Apply supplied rubber bumper using adhesive; attaching it to clean frame so that kickstand will not hit casing.

**Elwood Specialty Products Inc.**  
**2180 Elmwood Ave.**  
**Buffalo NY 14216**  
**Telephone(800)445-8946**  
**Fax(716)874-2110**